



Newfonic MicroAmp

Thank you for purchasing Newfonic MicroAmp. This manual has been included with your purchase so that you may utilise and enjoy all the features offered.

Setting up your MicroAmp

1. Connect Butt cable into handset socket of the telephone and the other end into Telephone socket "5".
2. Plug handset cable into Handset socket "6".
3. Plug headset cable into Headset socket "8".
4. Press Handset/Headset button "1" to desired option. (Left for handset or Right for headset)
5. Adjust Phone configuration switch "4" until you hear a dial tone.
6. Set Mute button "2" to the Up position.
7. Adjust Phone configuration switch "6" until party on the other end of the line can hear you clearly
8. Adjust Receive volume "7" until you can hear the party on the other end of the line comfortably.



- | | |
|-------------------------------|---------------------|
| 1. Handset / Handset switch | 5. Telephone socket |
| 2. Mute button | 6. Handset socket |
| 3. Mic Polarity switch | 7. Receive volume |
| 4. Phone Configuration switch | 8. Headset socket |



JPL Comms Ltd

Tel: 01258 820100

Fax: 01258 820550

www.jpltele.com